PARTS LIST
LISTE PIECES DETACHEES
ERSATZTEILLISTE
LISTA PARTI DI RICAMBIO
LISTA DE PIEZAS DE REPUESTO

THOMSON
VTCD1200
Chassis CRKD1241

MODULES

MAIN	**MAIN**	**R**	**35094870**
KDB	**DISPLAY/CONTROL**	**R**	**35094880**
POWE	**POWER**	**R**	**35095010**
RCPB	**CASSETTE**	**R**	**35094890**

IC101	TA2132F	35094750
IC102	LA1833L	35094770
IC103	LM7000	10542690
IC201,202	TC4052BP	10403350
IC203	TC9235P	35094760
IC301	TA8229K	35094780
IC601	UPD753016AGC-E86 FLAT	35094810
IC604	BU1923F	35094820
IC701	AN7312	35057270
REM60	RPM6938-V4	35090120

Q102,116,309,603	2SA733P-T	10232490
Q103,104,105,106,107,108,109,111,112,113,114,115,201,202,203,204,205,206,207,208,209,210,301,302,304,306,310,311,601,602,604,605,701,702,703,704,705	2SC945P	35055330
Q110	9018G	10403270
Q303	9012G	10391290
Q305	KSA928-Y/2SA928-Y	10400140
Q307	2SC1383R	10235690
Q308	2SD2012	10221820
Q312,313,706	8050C	10494170

D101,102,103,106,107,112,201,301,302,303,304,305,601,602,603,606,607,608,609,610,611,612,613,614,615,616,617,618,647,701,702	1N4148	44009209
D104,105	SVC201SPA	35045740
D108,109,110,111	SVC321SPA-C-2	10390850
D401,403,405,408	1N4001	16008160
D619	ELT-3143D LED	35094800
ZD101	BZX55C3V3	30948790
ZD102	BZX55C5V1/ZPD5V1	80444140
ZD103	BZX55C5V6/ZPD5V6	44025401
ZD301	BZX55C9V1	90578100
ZD302,304	ZPD10 2%	80444160
ZD305	BZX55C6V2	20475410



F101		35049070
F103	10M7HZ	35055340
F104	450K0HZ	35055350
F105	10MHZ7 FILTER	35033390
X101	7M2MHZ	35094790
X601	4M332HZ	35094830
X602	6M0HZ	35094840

T101		10390920
T102		10390910
T103		10390930
T104		35049060
T701		35023590

R319	1R0 OHM 5% 0,25W	⚠ 15009730
R326	10R0 OHM 5% 0,25W	⚠ 15009580

TC101	10P0F	35049040
TC103	30P0F	35035510

OTHER PARTS
AUTRES PIECES
SONSTIGE TEILE
ALTRE PARTI
OTRAS PIEZAS

D621	DISPLAY LCD AFFICHEUR LCD LCD-ANZEIGE VISUALIZZATORE LCD VISUALIZADOR LCD	35094630
F301	98°C/250V TIME-LAG FUSE 98°C/250V FUSIBLE THERMIQUE 98°C/250V THERMISCHE SICHERUNG 98°C/250V FUSIBILE 98°C/250V FUSIBLE	⚠ 10391460
F401	1A6T TIME-LAG FUSE 1A6T FUSIBLE TEMPORISE 1A6T SICHERUNG 1A6T FUSIBILE TEMPORIZZATO 1A6T FUSIBLE TEMPORIZADO	⚠ 48064700
F402	1A25T TIME-LAG FUSE 1A25T FUSIBLE TEMPORISE 1A25T SICHERUNG 1A25T FUSIBILE TEMPORRIZZATO 1A25T FUSIBLE TEMPORIZADO	⚠ 48006800
JK401	HEADPHONE SOCKET PRISE CASQUE KOPFHOERERBUCHSE PRESA JACK TOMA JACK	35049160
LM501,502,503	LAMP 12V AMPOULE 12V LAMPE 12V LAMPADA 12V LAMPARA 12V	35094850

R : RECYCLED PART
: PIECE RECYCLEE
: AUSTAUSCHTEILE
: RICAMBIO RICICLATO
: MODULO REPROCESADO

For any requests, please contact THOMSON multimedia after sales service area
Pour toutes précisions, contactez votre service apres vente local THOMSON multimedia
Für weitere Auskünfte, wenden Sie sich bitte an die THOMSON multimedia Kundendienste
Per precisazioni, contattare l'assistenza tecnica THOMSON multimedia
Para cualquier pregunta, por favor contactar con el responsable de zona del servicio postventa de THOMSON multimedia

08 / 1999 **35095020**
REV. N° 0 00 / 00 **00000000**

No copying, translation, modification on other use authorized. All rights reserved worldwide. • Tous droits de reproduction, de traduction, d'adaptation et d'exécution réservés pour tous les pays. • Sämtliche Urheberrechte an diesen Texten und Zeichnungen stehen uns zu. Nachdrucke, Vervielfältigungen - auch auszugsweise - nur mit unserer vorherigen Zustimmung zulässig. Alle Rechte vorbehalten. • I diritti di riproduzione, di traduzione, e esecuzione sono riservati per tutti i paesi. • Derechos de reproduccion, de traduccion, de adaptacion y de ejecucion reservados para todos los paises.

SPK301	LOUDSPEAKER SOCKET PRISE HAUT PARLEUR LAUTSPRECHERBUCHSE PRESA ALTOPARLANTE TOMA HEMBRA ALTAVOZ	10494310
SW600	SLIDE SWITCH COMMUTATEUR SCHALTER COMMUTATORE CONMUTADOR	35094860
SW601,602, 603,604,605, 606,607,608, 609,610,611, 612,613,614, 615,616,617, 618,619,620	MICROSWITCH MICRO CONTACTEUR MIKROSCHALTER MICROINTERRUTTORE MICROCONTACTOR	10449940
SW701	SWITCH COMMUTATEUR SCHALTER COMMUTATORE CONMUTADOR	10449930

EQUIPMENT/PRESENTATION
EQUIPEMENT/PRESENTATION
AUSSTATTUNG/GEHAEUSE
PARTI VARIE
EQUIPO/PRESENTACION

LOUDSPEAKER BOX RIGHT OR LEFT ENCEINTE ACOUSTIQUE GAUCHE OU DROITE LAUTSPRECHERBOX RECHTS ODER LINKS CASSA ACUSTICA SINISTRA O DESTRA CAJA ACUSTICA IZQUIERDA O DERECHA	35095040
VTCD1200 (REMOTE CONTROL) VTCD1200 (TELECOMMANDE) VTCD1200 (FERNBEDIENUNG) VTCD1200 (TELECOMANDO VTCD1200 (TELEMANDO)	35093820
POWER SUPPLY LEAD CORDON D'ALIMENTATION NETZKABEL CAVO DI ALIMENTAZIONE CABLE DE ALIMENTACION	⚠ 10260820

MECHANISM
MECANIQUE
MECHANIK
MECCANICA
MECANISMO

CASSETTE MECHANISM MECANIQUE CASSETTE CASSETTENLAUFWERK MECCANICA CASSETTA MECANISMO CASSETTE	35089510
BUSH RUBBER CD REAR AMORTISSEUR CAOUTCHOUC CD ARRIERE DAEMPER GUMMI CD HINTEN AMMORTZZATORE DI GOMMA CD POSTERIORE AMORTIGUADOR DE GOMA CD TRASERA	35055560
BUSH RUBBER CD FRONT AMORTISSEUR CAOUTCHOUC CD AVANT DAEMPER GUMMI CD VORN AMMORTIZZATORE DI GOMMA CD ANTERIORE AMORTIGUADOR DE GOMA CD DELANTERA	35051630
OPTICAL PLAYER TCM-125-2 LECTEUR OPTIQUE TCM-125-2 PICK-UP TCM-125-2 ASSIEME OTTICA TCM-125-2 MECANISMO OPTICO TCM-125-2	10612760
EG530AD-2B MOTOR 12V EG-530AD-2B MOTEUR 12V EG530AD-2B MOTOR 12V EG530AD-2B MOTORE 12V EG530AD-2B MOTOR 12V	10218650



VTCD1200 UM TH VTCD1200 NU TH VTCD1200 BA TH VTCD1200 IU TH VTCD1200 IU TH	55017810
VTCD1200 PARTS LIST VTCD1200 LISTE DE PIECES DETACHEES VTCD1200 ERSATZTEILLISTE VTCD1200 LISTA PARTI DI RICAMBIO VTCD1200 LISTA DE PIEZAS DE REPUESTO	35095020
CRKD1241 SERVICE MANUAL CRKD1241 DOCUMENTATION TECHNIQUE CRKD1241 TECHNISCHE DOKUMENTATION CRKD1241 DOCUMENTAZIONE TECNICA CRKD1241 DOCUMENTACION TECNICA	35089890

COPIER VUE ECLATEE
COPIER VUE ECLATEE
COPIER VUE ECLATEE
COPIER VUE ECLATEE
COPIER VUE ECLATEE

001	CASSETTE FLAP WINDOW GLACE VOLET CASSETTE FENSTER CASSETTENKLAPPE VETRO SPORTELLO CASSETTA CRISTAL TAPA CASSETTE	35089040
002	CASSETTE FLAP DOOR VOLET CASSETTE CASSETTENKLAPPE SPORTELLO CASSETTA TAPA CASSETTE	35089050
003	CASSETTE HOLDER PORTE CASSETTE CASSETTENHALTER PORTACASSETTA PORTACASSETTE	35089060
004	SPRING TORSION HOLDER CASSETTE RESSORT A EPINGLE VOLET CASSETTE NADELFEDER CASSETTENKLAPPE MOLLA DI TORSIONE PORTACASSETTA RESORTE HORQUILLA PORTACASETTE	35089070
007	VOLUME KNOB BOUTON VOLUME LAUTSTAERKEKNOPF ROTELLA DI PLASTICA VOLUME RUEDA PLASTICA MANDO VOLUMEN	35094530
008	MONO/STEREO SLIDE BUTTON MANETTE MONO/STEREO MONO/STEREO SCHIEBETASTE COMMANDO A CURSORE MONO/STEREO MANECILLA MONO/STEREO	35094540
009	DISPLAY WINDOW GLACE AFFICHEUR ANZEIGEFENSTER VETRO DEL VISUALZZATORE CRISTAL DEL VISUALIZADOR	35094910
010	FRONT PANEL FACADE FRONTPLATTE PANNELLO FRONTALE PANEL FRONTAL	35094920
015	CASSETTE BUTTON ASSY ENSEMBLE DE TOUCHES CASSETTE TASTENEINHEIT CASSETTE ASSIEME TASTI CASSETTA CONJUNTO DE TECLAS CASSETTE	35094360
022	CASSETTE DOOR DAMPER GEAR ROUE DENTEE PORTE CASSETTE ZAHNRAD CASSETTENHALTER RUOTA DENTATA PORTACASSETTA RUEDA DENTADA PORTACASSETTE	35095000
023	GEAR WHEEL CASSETTE HOLDER SUPPORT ROUE DENTEE PORTE CASSETTE HALTER ZAHNRAD SUPPORTO RUOTA DENTADA PORTACASSETTA SOPORTE RUEDA DENTADA PORTACASSETTE	35094990
024	BUTTON STRIP CD CONTROL/PRESET BARRETTE DE TOUCHES 8T CD/PRESET TASTENLEISTE CD CONTROL/PRESET PIATTINA TASTIES 8T CD CONTROL/PRESET PLACA DE TECLAS 8T CD CONTROL/PRESET	35094560
025	TIME/MIX BUTTON BARRETTE DE TOUCHES 2T TIME/MIX TASTENLEISTE TIME/MIX PIATTINA TASTI TIME/MIX PLACA DE TECLAS TIME/MIX	35094570
026	BUTTON STRIP POWER/PROGRAM BARRETTE DE TOUCHES 2T POWER/ PROGRAM TASTENLEISTE POWER/PROGRAM PIATTINA TASTI 2T POWER/PROGRAM PLACA DE TECLAS 2T POWER/PROGRAM	35094580
027	SUPPORT BUTTONS CD/TAPE/TUNER SUPPORT DE TOUCHES CD/TAPE/TUNER HALTER KUNSTSTOFF CD/TAPE/TUNER SUPPORTO TASTI CD/TAPE/TUNER SOPORTE TECLAS CD/TAPE/TUNER	35094930
028	CD BUTTON TOUCHE CD TASTE CD TASTO CD TECLA CD	35094590
029	TAPE BUTTON TOUCHE TAPE TASTE TAPE TASTO TAPE TECLA TAPE	35094600
030	TUNER BUTTON TOUCHE TUNER TASTE TUNER TASTO TUNER TECLA TUNER	35094610
031	BUTTON STRIP RDS/DISPLAY/TIME BARRETTE DE TOUCHES RDS/DISPLAY/TIME TASTENLEISTE RDS/DISPLAY/TIME PIATTINA TASTI RDS/DISPLAY/TIME PLACA DE TECLAS RDS/DISPLAY/TIME	35094620
035	CASSETTE BOARD CASSETTE PLATINE CASSETTE PLATTE CASSETTE PIASTRA CASSETTE PLATINA	35094890
042	DISPLAY/CONTROL BOARD DISPLAY/CONTROL PLATINE DISPLAY/CONTROL PLATTE DISPLAY/CONTROL PIASTRA DISPLAY/CONTROL PLATINA	35094880
044	MAIN BOARD MAIN PLATINE MAIN PLATTE MAIN PIASTRA MAIN PLATINA	35094870
050	SWITCHED MODE TRANSFORMER TRANSFORMATEUR D'ALIMENTATION TRAFO SCHALTNETZTEIL TRASFORMATORE D'ALIMENTAZIONE TRANSFORMADOR DE ALIMENTACION	⚠ 35094640
052	POWER BOARD POWER PLATINE POWER PLATTE POWER PIASTRA POWER PLATINA	35095010
053	REAR PANEL COFFRET ARRIERE RUECKWAND PANNELLO POSTERIORE TAPA POSTERIOR	⚠ 35094940

065	COUNTER CENTRIRING PART CONTRE CENTREUR GEGENZENTRIERSTUECK CONTROCENTRATORE CONTRA ADAPTADOR	35090230
066	MAGNET CD AIMANT CD MAGNET CD MAGNETE CD IMAN CD	35051560
068	COUNTER CENTRIRING HOLDER SUPPORT CONTRE CENTREUR GEGENZENTRIERSTUECK HALTER SUPPORT0 CONTROCENTRATORE SOPORTE CONTRA ADAPTADOR	35051520
070	CD LOCK MAGNET VERROU AIMANT CD RIEGEL MAGNET CD CHIUSURA MAGNETE CD CERROJO IMAN CD	35051550
071	CD DOOR VOLET CD CD KLAPPE SPORTELLO CD TAPA CD	35094950
072	LOOK CD DOOR VERROU VOLET CD RIEGEL CD KLAPPE CHIUSURA SPORTELLO CD CERROJO TAPA CD	35089250
074	CD OPEN LEVER LEVIER OUVERTURE VOLET CD HEBEL (DOOR CD) LEVA APERTURA SPORTELLO CD LEVA APERTURA TAPA CD	35090240
080	SPRING TORSION CD DOOR RESSORT A EPINGLE VOLET CD NADELFEDER CD KLAPPE MOLLA DI TORSIONE SPORTELLO CD RESSORTE HORQUILLA TAPA CD	35095170
081	SUPPORT CD MECHANISM SUPPORT MECANIQUE CD HALTER CD LAUFWERK SUPPORTO MECCANICA CD SOPORTE MECANISMO CD	35089270
082	CD DOOR DAMPER GEAR ROUE DENTEE VOLET CD ZAHNRAD CD HALTER RUOTA DENTATA SPORTELLO CD RUEDA DENTADA TAPA CD	35089280
083	GEAR WHEEL CD HOLDER SUPPORT ROUE DENTEE VOLET CD HALTER ZAHNRAD SUPPORTO RUOTA DENTADA SPORTELLO CD SOPORTE RUEDA DENTADA TAPA CD	35089290



CHASSIS AND PRESENTATION / CHASSIS ET PRESENTATION / CHASSIS UND GEHAEUSETEILE / TELAIO E DI PRESENTAZIONE / CHASIS Y PRESENTACION

VTCD1200

The description and characteristics given here are of informative significance only, and non committal. To keep up the high quality of our products, we reserve the right to make any changes or improvement without previous notice. • Les descriptions et caractéristiques figurant sur ce document sont données à titre d'information et non d'engagement. En effet, soucieux de la qualité de nos produits, nous nous réservons le droit d'effectuer, sans préavis, toute modification ou amélioration. • Die Beschreibungen und Daten in dieser Anleitung dienen nur zur Information und sind nicht bindend. Um die Qualität unserer Produkte ständig zu verbessern, behalten wir uns das Recht auf Änderungen vor. • Le descrizioni e le caratteristiche date su questo documento sono fornite a semplice titolo informativo e senza impegno. Ci riserviamo il diritto di eseguire, senza preavviso, qualsiasi modifica o miglioramento. • Las descripciones y características que figuran en este documento se dan a título de información y no de compromiso. En efecto, en bien de la calidad de nuestros productos, nos reservamos el derecho de efectuar, sin previo aviso, cualquier modificación o mejora.

THOMSON multimedia S.A au capital de 4 594 812 200 FF - 46, Quai Alphonse Le Gallo 92648 Boulogne Cedex FRANCE - RCS NANTERRE B 333 773 174

RCD124[illegible] VTCD[illegible]

MAIN PCB

LCD PCB

0621
DISPLAY

IC501
UPD753016

IC101
TA2132

IC102
LA1833

IC103
LM7000

IC604
BU1923

IC201 TC40S23P

IC202 TC40S23P

IC203
TC9223P

IC1
TA8229K

IC602
TC40H348P

IC503
TC4094BP

IC701
AN7312

CASS PCB

M201
MOTOR

CASS DECK

LCD BACK LIGHT

TO CD PCB

TO CD PCB

SW24
TWST/BEAT SW

SW600
VOLUME SW

JK401
HEADPHONE

3.2 OHM SPEAK

COMP

REMARK:
⚠ THIS MARK INDICATES THAT THE ADJACCENT COMPONENT IS CONSIDERED CRITICAL WITH RESPECT TO THE RISK OF FIRE AND ELECTRICAL SHOCK ASSOCIATED WITH THIS PRODUCT. WHEN REPLACING ANY OF THESE COMPONENT, USE ONLY PARTS SUPPLIED BY MANUFACTURER PART NUMBERS APL.

THOMSON CONSUMER ELECTRONICS
SALES GMBH
Funkschneise 13 · 28309 Bremen
VTCD 1200

ORION POWER ELECTRONIC CO., LTD			
MODEL NO:	RCD124I/THOMSON	VER	00
DRAWN BY:	LL LAU	DATE.	1999-4-6
CHECKED BY:		DATE.	
APPROVED BY:		DATE.	

MAIN PCB

CASS PCB

IC101 TA2132

IC102 LA1833

IC103 LM7000

IC701 AN7312

IC201 TC40D329P

Q102 A733

Q110 9018G

Q101 Q102 SVC201

Q103 Q104 Q105 Q106 Q107 Q108 C945

Q109 Q110 Q111 SVC321

Q112 Q113 Q114 C945

Q116 A733

Q201 Q202 Q203 Q204 Q205 Q206 C945

Q210 C945

Q301 3050

Q701 Q702 Q703 Q704 Q705 C945

Q707 4148

ZD101 3V3

ZD102 3V1

ZD103 5V6

D101 D102 SVC201

D103 D104 SVC201

D105 SVC201

D106 D107 D108 SVC321

D109 SVC321

D111 SVC321

D112 D113 4148

D501 LED

D013 LED

F101 BPF 88108

F103 10.7M

F104 450

F105 10.7M

T101 T102 AM IFT

T103 T104 LW OSC

T701 325M

L101 0.22uH

L102 2.5T 3.5MM

L103 2.5T 3.0MM

L104 10uH

L105 SW 24 MW ANT

L106 220-30 LW ANT

L301 220u

X101 7.2MHz

M201 MOTOR

CASS DECK

LSW

MAGNET

TO CD PCB

CD10V

FMVT

AMVT

FM ANT

CN201

BIAS GND

BEAT CUT

ST SIG

SEAT GND SYNC

*MARK:

⚠ THIS MARK INDICATES THAT THE ADJACCENT COMPONEN

CRITICAL WITH RESPECT TO THE RISK OF FIRE AND EL

ASSOCIATED WITH THIS PRODUCT. WHEN REPLACING ANY OF

USE ONLY PARTS SUPPLIED BY MANFACTURER PART NUMBER

R1012F1

MAIN PCB

LCD PCB

0621
DISPLAY

IC501
UPD753016

IC102
LA1833

IC103
LM7000

IC201 TC40529P

IC202 TC40529P

IC604
BU1923

Q102 A733
Q103 C945
Q104 C945
Q116 A733
Q201 C945
Q202 C945
Q203 C945
Q204 C945
Q205 C945
Q206 C945
Q207 C945
Q209 C945
Q210 C945
Q111 C945
Q112 C945
Q113 C945
Q114 C945
Q115 C945
Q601 C945
Q602 C945
Q603 A733
Q604 C945
Q701 C945
Q702 C945
Q307 9050C
Q308 D2012
Q312 9050C
Q313 9050C

D102 4148
D106
D107
D112
D501 LED
D13 LED
D602
D606
D607
D617
D701 4148
ZD103 5V6
ZD301 8V1
ZD302 10V
ZD304 10V
ZD305 4V7

X101 7.2MHz
X501 4.332MHz
T102 AM IFT
F104 450
F105 10.7M

R118 10K
R112 100 1/4W
R152 150 1/4W
R151 150 1/4W
R163 3K3
R130 20K
R135 22K
R114 47K
R119 47K
R132 10K
R129 68K
R156 10K
R157 0K
R158 5K2
R159 3K3
R160 3K3
R161 47
R162 10K
R164 8K2
R165 220
R166 100K
R167 10K
R155 10K
R396 22K
R117 47K
R113 3K
R115 220
R121 10K
R126 5K6
R125 5K6
R128 22K
R127 22K
R137 4K7
R136 4K7
R253 47K
R262 47K
R123 10K
R122 10K
R120 10K
R168 100K
R124 10K
R614 1K
R615 10K
R616 47K
R611 10K
R612 10K
R613 10K
R631 1K
R632 1K
R635 47K
R623 1K
R625 1K
R629 1K
R627 47K
R633 1K
R624 47K
R643 47K
R622 47K
R641 47K
R647 47K
R646 47K
R660 220
R648 10K
R649 100K
R712 47K
R711 47K
R710 560
R717 10K
R718 10K
R731 12K
R730 47K
R725 47K
R726 47K
R202 22K
R201 22K
R204 560K
R205 2K2
R210 270
R211 270
R203 560K
R206 2K2
R207 1K
R209 2K2
R208 2K2
R212 4K7
R213 4K7
R214 2K2
R215 10K
R216 27K
R217 27K
R218 10K
R219 10K
R220 3K3
R221 3K3
R222 22K
R223 22K
R224 18K
R225 5K6
R226 33K
R227 33K
R228 82K
R229 82K
R230 18K
R231 18K
R232 27K
R233 27K
R234 39K
R235 39K
R236 27K
R237 27K
R238 27K
R239 27K
R240 560K
R241 560K
R244 330
R246 2K2
R247 330
R245 2K2
R248 1K
R249 NU
R256 NU
R257 100K
R243 27K
R254 1K3
R267 8K2
R256 8K2
R255 1K2
R501
R503 22 1/4W
R318 820 1/4W
R319 1 1/4W
R326 0
R327 820
R329 2K2
R330 220 1/4W
R321 330 1/4W

C122 104
C141 330P
C123 220u
C136 330P
C135 472
C134 103
C142 223
C144 473
C143 22n
C139 273M
C138 10n
C137 4u7
C140 330P
C133 68K
C152 102
C168 30
C167 100
C179 100u
C171 103
C177 33P(NPO)
C178 33P(NPO)
C164 470u
C176 104
C173 104
C172 0.33U
C175 104
C174 104
C170 203
C165 100u
C179 203
C128 102
C145 123
C126 3n
C125 0.47u
C131 153M
C130 153M
C432 203
C433 203
C121 203
C120 100u
C150 222M
C151 222M
C714 1u
C713 1u
C202 100u
C201 203
C259 2K2
C203 1u
C204 1u
C205 1u
C206 1u
C207 10u
C208 100u
C209 203
C210 100u
C211 203
C212 222M
C213 222M
C214 333M
C215 333M
C216 822M
C217 322M
C218 122M
C219 122M
C220 202M
C221 202M
C222 103M
C223 103M
C224 1u
C225 100u
C226 1u
C227 203
C229 680P
C243 470u
C244 100u
C245 100u
C246 100u
C247 100u
C248 100u
C249 100u
C650 560
C647 203
C646 560
C604 2u2
C515 100u
C516 104
C617 201
C618 33P(NPO)
C543 33P(NPO)
C622 104
C611 623
C612 100
C623 623
C614 330
C615 330
C539 104
C609 10u
C610 10u
C603 103
C601 103
C602 103
C322 100u
C321 100u
C324 100u
C325 100u
C326 100u
C327 203
C330 100u
C320 100u
C310 100u
C311 100u
C312 100u
C313 100u
C314 100u
C232 100u
C233 470u
C231 100u
C230 100u
C234 100u
C235 100u
C236 100u
C237 100u
C238 100u
C239 100u
C240 100u
C241 100u
C242 100u
C243 100u
C244 100u
C245 100u
C246 100u
C247 100u
C248 100u
C249 100u
C250 100u
C251 100u
C252 100u
C253 100u
C254 100u
C255 100u
C256 100u
C257 100u
C258 100u
C259 100u
C260 100u
C261 100u
C262 100u
C263 100u
C264 100u
C265 100u
C266 100u
C267 100u
C268 100u
C269 100u
C270 100u
C271 100u
C272 100u
C273 100u
C274 100u
C275 100u
C276 100u
C277 100u
C278 100u
C279 100u
C280 100u
C281 100u
C282 100u
C283 100u
C284 100u
C285 100u
C286 100u
C287 100u
C288 100u
C289 100u
C290 100u
C291 100u
C292 100u
C293 100u
C294 100u
C295 100u
C296 100u
C297 100u
C298 100u
C299 100u
C300 100u
C301 100u
C302 100u
C303 100u
C304 100u
C305 100u
C306 100u
C307 100u
C308 100u
C309 100u
C310 100u
C311 100u
C312 100u
C313 100u
C314 100u
C315 100u
C316 100u
C317 100u
C318 100u
C319 100u
C320 100u
C321 100u
C322 100u
C323 100u
C324 100u
C325 100u
C326 100u
C327 100u
C328 100u
C329 100u
C330 100u
C331 100u
C332 100u
C333 100u
C334 100u
C335 100u
C336 100u
C337 100u
C338 100u
C339 100u
C340 100u
C341 100u
C342 100u
C343 100u
C344 100u
C345 100u
C346 100u
C347 100u
C348 100u
C349 100u
C350 100u
C351 100u
C352 100u
C353 100u
C354 100u
C355 100u
C356 100u
C357 100u
C358 100u
C359 100u
C360 100u
C361 100u
C362 100u
C363 100u
C364 100u
C365 100u
C366 100u
C367 100u
C368 100u
C369 100u
C370 100u
C371 100u
C372 100u
C373 100u
C374 100u
C375 100u
C376 100u
C377 100u
C378 100u
C379 100u
C380 100u
C381 100u
C382 100u
C383 100u
C384 100u
C385 100u
C386 100u
C387 100u
C388 100u
C389 100u
C390 100u
C391 100u
C392 100u
C393 100u
C394 100u
C395 100u
C396 100u
C397 100u
C398 100u
C399 100u
C400 100u

L501 100u

SW24 FWST/BCAT SW

D0608
D0603 A733

ZD103 5V6

FWST/BCAT
SYNC
SCL
SDA
MUTE
5V
GND

SYNC
BCAT
GND
SCL
SDA
9V
COM

CD10V
LGND
LOUT R
LGND
LOUT L

TO CD PCB

LCD BACK LIGHT

REMARK:
THIS MARK INDICATES THAT THE ADJACCENT COMPONENT IS CONSIDERED CRITICAL WITH RESPECT TO THE RISK OF FIRE AND ELECTRICAL SHOCK ASSOCIATED WITH THIS PRODUCT. WHEN REPLACING ANY OF THESE COMPONENT, USE ONLY PARTS SUPPLIED BY MANUFACTURER PART NUMBERS APP.

THOMSON CONSUMER ELECTRONI
SALES GMBH
Funkschneise 13 · 28309 Bremen

VTCD 1200



THOMSON CONSUMER ELECTRONICS
SALES GMBH
Funkschneise 13 · 28309 Bremen

VTCD 1200